

67-69 Camaro Rear
Left Side

Turn post clockwise to bring front of glass inside.

Turn post clockwise to bring rear of glass inside.

Turn post clockwise to let top of glass out. Also
move forward in slot to tilt the top of the glass
to the rear.

*The upper stop adjustment is on the arm of the
regulator.

