

68-72 Chevelle Right Rear

Factory Stop must be relocated to under side of Arm



Bolt Factory Stop in Place

Add 5/16 Hole