

32 Ford 3 Window

**Instructions: Drilling Holes for Idler Bar
Drilling Access Holes for Lower Glass Channels**

