



Glass placement on Channel is Key!

1. Mark the measurements on regulator as shown.
2. Using a square, continue the center line up to the glass opening
3. Place the glass in the opening and slide forward until sealed
4. Using a Sharpie, mark the line on the glass
5. Place the glass on the channel where the line marked will line up with the center on the roller stud hole.
6. Place system in door, leaving the mounting screws loose.
7. Bump (Do not hold down) switch until roller is free in slot on arm
8. Snug up screws and test. If glass does not seal properly, loosen screws and bump switch again.