

53-55 Ford Truck No Vent
Left Side

- *Remove vent window assembly and all old parts.
 - *To install front vertical channel, make a square mark down the door for reference.
 - *As you can see, your mark overlaps part of the upper hinge. This will need to be cut back for clearance of the vertical channel.
 - *Use the bracket at the bottom to secure channel to door skin.
 - *Bolt regulator in factory location.
- *If you are using flat glass, the door will need to be cut and straightened at the vent window.
- *There is a company that makes curved glass to fit door.
- *If using curved glass, you will need to bend the lower glass track to match.

