

64-66 Mustang Tip Sheet

- Install wire harness to each door. Place regulator in door. Plug wires to motor before bolting in so you can reach motor plugs
- **All stops must be installed** before running all the way up or down – (see pictures).
- If rear up stop is not installed, regulator can push the window to high in the back. This will cause it to bind when you try to roll it back down. This could result in a bent regulator or worse – a broken glass.
- Lubricate felts with silicone spray and grease tracks, rollers and gear teeth. If tracks have original felts be sure it is not rolling up.